



SHINOLA
DETROIT

TRAVEL ALARM CLOCK GUIDE


Your clock comes with a new SR44 battery we installed at our Detroit factory just before shipping. To engage the battery, gently pull the tab from underneath the battery cover. To change the battery, please follow the directions below.

CHANGING THE BATTERY

1. Gently place your clock face down on a soft surface that will not scratch the glass or metal.
2. Do not press down on the back plate of the clock as you will crack the glass with pressure.
3. Gently unscrew the battery cover. SEE IMAGE.
4. After you change the battery, lightly screw the cover back in. Make sure not to apply too much pressure as it could potentially cause damage to the clock casing and glass.

SETTING THE CLOCK TIME

1. Rotate the time wheel counterclockwise until the desired time is reached. SEE IMAGE.



SETTING THE ALARM TIME

1. Rotate the alarm wheel clockwise until the desired time is reached
Caution: Turning the wheel in the wrong direction can potentially disrupt proper alarm function.
2. Turn the alarm on by switching the function to the on position. SEE IMAGE.
3. To turn the alarm off, switch the alarm function to the off position.

Please Note: When setting the alarm, remember to always turn the wheel in the correct direction, even if you pass your desired time. Turning it in the wrong direction can cause the alarm to function improperly. The alarm may sound within 5 minutes before or after the set time. This is a normal function of the alarm clock.

LIMITED WARRANTY

Our belief is that products should be built to last. To back up that claim, we have created a limited guarantee that ensures every Shinola Alarm Clock is free from defects in material and workmanship under normal use and service for a period of one (1) year from the date of purchase. This warranty is limited to the replacement, repair or refund of the purchase price, at Shinola's election, within the warranty period and does not extend to consequential or incidental damage to other products that may be used with this unit.

The remedies for any failure of a Shinola Alarm Clock to meet this warranty shall be those remedies stated herein and no other; these being the exclusive remedies as a condition of sale irrespective of the theory upon which any claim may be based, including without limitation, negligence, breach of contract or strict liability. Except as expressly set forth herein, Shinola makes no warranty, express or implied, including any warranty of merchantability or fitness for any particular purpose.

The foregoing warranty shall be voided by any repair, alteration, or modification by persons other than the employees of Shinola, and by any abuse, misuse or neglect of the products or by use not in accordance with the Shinola published instructions.

WE ARE HERE TO HELP YOU

If you have any concerns or questions, don't hesitate to contact us. There are three ways to get in touch. Fill out the contact form on our website at Shinola.com, give us a call or send us an email.

GENERAL CUSTOMER SERVICE

Monday - Friday
8:30AM - 6PM EST
1.844.SHINOLA
customerservice@shinola.com